

# Features Evaluation Module Accessory

- Accessory for the R-78S3.3-0.1-EVM-1
- Mates with STLCS01V1

**RECOM**  
Evaluation Module  
Accessory


**R-78S3.3-0.1-EVM-1/STM-1**

## Description

The R-78S3.3-0.1-EVM-1/STM-1 is a breakout board developed to be used with an ST Microelectronics STEVAL STLCS01V1 SensorTile<sup>(1)</sup> module and the R-78S3.3-0.1-EVM-1 evaluation module to demonstrate IoT applications using the SensorTile module. Functions of the SensorTile module include MEMS digital microphone, 3D accelerometer and gyroscope, 3D magnetometer, MEMS atmospheric pressure sensor and ambient temperature.

### Notes:

Note1: The STEVAL STLCS01V1 from ST Microelectronics is not provided by RECOM.




## Quick Start Guide

- Insert the AA battery into the battery holder.
- Insert the SensorTile module onto the R-78S3.3-0.1-EVM-1/STM-1, and plug into header J7 (refer to picture R-78S3.3-0.1-EVM-1/STM-1 with the SensorTile for correct orientation).
- Turn on using the switch on the R-78S3.3-0.1-EVM-1 (Note: to reduce the power consumption, no indicator LED is fitted). Remember to switch off to conserve the battery.
- To connect with the SensorTile module, download and install the ST BlueMS App on your mobile phone and touch "START SCANNING".




- This breakout board only connects to the power terminals of the SensorTile module.
- Communication is via Bluetooth (App available from ST).
- The vias (U1) mate with the SensorTile to connect to the snap-in connector CN1. They can also be used as measuring points if needed.

## Layout




[www.recom-power.com/eval-ref-boards](http://www.recom-power.com/eval-ref-boards)

## Schematic



R-78S3.3-0.1-EVM-1/STM-1 with the SensorTile



Assembled R-78S3.3-0.1-EVM-1/STM-1 on the R-78S3.3-0.1-EVM-1

