



SUPPLY CHAIN MANAGEMENT WHITEPAPER

V1.0 EN



This whitepaper shares some design guidelines and advice on how to reduce failure causes and simplify the design - with application examples for a better comprehension.





INTRODUCTION

In cooperation with our partner RECOM and based on their recent activities to address the geopolitical challenges facing the electronics industry supply chains, we are pleased to provide you with this white paper.

Reliable supply chain and state-of-the-art products

RECOM manufactures a full range of standard and custom DC/DC and AC/DC converters for IoT, Industry 4.0, Energy & Power, Medical, and Transportation, including switching regulators and LED drivers, from sub-1W to tens of kW. The manufacturer has become synonymous with high quality, integrity, innovation, and excellent customer service in the electronics industry.

RECOM with expanded activities. Available from Rutronik with shorter lead times.

In combination with Rutronik's logistics services, this is the solution to reduce risks and eliminate disruptions in the supply chain. Based on the long-standing partnership between RECOM and Rutronik, you benefit from an efficient product flow that follows their global footprint.

TABLE OF CONTENT

GENERAL INFORMATION	2
IT ALL STARTS WITH THE FUNCTIONAL SPECIFICATION	3
WORKING WITH PROCUREMENT/COMMODITIES STAKEHOLDERS	4
ENTERPRISE RESOURCE PLANNING (ERP)	6
WORKING WITH THE POWER SOLUTION VENDOR	7
SUMMARY/CONCLUSIONS & FOLLOW-ON INFO	8
REFERENCES	8

GENERAL INFORMATION

This white paper was created in conjunction with another, complementary white paper focused on supply chain management. While the two may have a similar look and feel on related topics, it should be noted this white paper focuses on how to manage the supply chain resources identified in the preceding document and facilitate managing those vendors. NOTE: the term "vendor" is used loosely here and could easily apply to an organization's internal resource management.

In other words, the last white paper focused on the tools for performing feasibility, while this one focuses more on the execution aspects. Again, though there may be some overlap in key topic areas, the content of each takes on differentiating and meaningful context and should therefore be treated as such.

RECOM

IT ALL STARTS WITH THE FUNCTIONAL SPECIFICATION

Everything from design to supply chain to any other critical, system-development dependency starts with a proper functional specification (spec). If the bar is not set correctly at the onset, the issues/risks/COSTS only magnify as the schedule progresses. It is quite common to put a lot of pressure on the design engineering resources to set a design in motion even before specifications are fully baked out. This is particularly true for smaller/fresher organizations, where resources are scant and the end of the funding runway if often on the horizon.

When it comes to developing power supplies and associated, powered solutions, this pressure will likely end up being funneled to the power electronics engineer or analogous team stakeholder having first-order responsibility to deliver system power infrastructure. They must stay strong in the face of this pressure and be vigilant in insisting system architects and other design partners sit down and have the necessary discussions and not except too many "TBD" (to be determined) placeholders for critical specs. This is not to say there should be an expectation of a final-quality document at project onset, which should certainly be tweaked and optimized as the development progresses, but even a draft spec should not be so broad and/or nebulous so as to inhibit (high-quality, timely) developments. Many functional requirements and certifications are out of the hands of the power solution designer/owner, even if they have ultimate responsibility for successfully delivering the solution. Examples include derating guidelines (i.e. – IPC-9592, internal design guides, etc.), specialized certifications (i.e. – EN51055, 80PLUS, EMC class A/B, DoE Level VI, NEBS, etc.), digital interfaces with system SW/FW, and full environmental operating scenarios (inc. compatibility with elevation and pollution/harsh environments). Many of these are not just stickers or rubber stamps to complete an aesthetic at assembly, but will have significant impacts on operating parameters (i.e. – minimum efficiency requirements, wider operating temperatures, more robust shock/vibe/electrical withstand, etc.) that can dictate the design from Day 1. The key takeaway is to be unrelenting with other stakeholders that lack the understanding/appreciation for what they are requesting and think these are questions that can be answered much later in the development process because when things go wrong, all that anyone remembers is that the "power person" is responsible for ANYTHING that inhibits successful shipment and field deployment.

A quintessential example of these communication gaps is when power subsystems implement digital reporting (control is not necessarily implied), which means a power converter can "talk" to the system via a digital bus and often, the system may have the ability to talk back. The only way these two components can be effectively designed to successfully operate cohesively and robustly in the application environment is if the HW and SW engineering stakeholders can come together to develop each of their respective, functional specifications (one for the converter, one for the system). The power stakeholder is unlikely to have the knowledge/experience to specify the digital bus characteristics, register assignments, and fault code formatting (to give a brief sampling of a long list items) autonomously. The SW/ FW stakeholder is unlikely to have the knowledge/experience to specify fault thresholds, power supply states/behaviors, and protection circuitry. Mitigating the gap in team communications between HW and SW engineering (as one example) is absolutely essential for successful development of a minimally-viable functional specification in just about any modern system.

To further make the point, it should be noted a solid functional spec is also a key enabler of the request-for-quote/proposal (RFQ/RFP) process, assuming a design is put out for bidding on by third parties. Everything from unit/warranty costs (inc. quality/reliability) to the development schedule to the availability of necessary resources to supply chain assurance of supply (AOS) to the financial viability of both the vendor and end-user organizations (in the most extreme cases) will be determined by the requirements set forth in the functional spec. This includes key items like safety/compliance/certification needs and design/qualification guidelines that must be followed.

When embarking on a new project, do you have what you need to generate a sufficient functional spec? Do you have the critical inputs of constraints from other engineering groups, program managers, and supply chain stakeholders? If Marketing cannot produce a product requirements doc (PRD, a.k.a. – marketing requirements doc or MRD) or equivalent, then how can you be expected to develop a proper functional spec for solutions to effectively meet those requirements? While it seems silly to say this, sometimes it is important to question if the requirements/specs being dictated are even pragmatically feasible with modern technology (or even fundamental physics sometimes). If your converter is required to have a transient response of 1MA/ns or support an operating environment of 500°C, then Houston, we have a problem!





WORKING WITH PROCUREMENT/COMMODITIES STAKEHOLDERS



The previous, complementary white paper provided a more in-depth analysis into multisourcing, what it is, how it can be interpreted, and some considerations (positive and negative) for performing a proper assessment of one's resources and making an informed decision. In short, the different considerations really seem to boil down to a focus on mitigating technical risk versus pricing leverage. As a further reminder, the objectives of stakeholders (internal/external, engineering/supply chain the like) are typically in conflict, both in execution as well as the priorities driving them. Here, we shall take that assessment and expand upon it to turn the analysis into more actionable strategies for driving results.

Assuming the final decision has been made to implement some kind of multisourcing strategy, the first step is for Design Engineering to determine the "critical components" list for analysis. The term is in quotes because the characterization of what is critical can be highly subjective and variable. Even trying to simplify with rules like "only the power components" or "only the hottest components" or "only the components most critical to safety" will often lead to grey areas and points of dissent. Regardless, it is important to work closely with teammates (especially those in Component/Reliability Engineering and Supply Chain Management) to negotiate through the tradeoffs of performance, cost, time-to-market (TTM), and AOS.

Component/Reliability Engineering is typically the least concerned with cost, which means they can dictate many qualification/life tests that can be extremely expensive, time consuming, and require 3rd-party resources (each time one takes direct control away, it adds risk

RECOM

to the development and schedule). First negotiating with these stakeholders on the minimum list of critical components, with proper justifications for either accepting or eliminating items on the critical components list, is an excellent origin point. An example of a compromise proposal may be if a component can be assessed with more virtual/statistical methods (such as Monte Carlo analysis [1] or vendor random sampling data) instead of the far more comprehensive, thermal/electrical stress and accelerated life testing.

Any such "real" (e.g. – physical/environmental) tests will not only need to consider the qualification on the individual component, but also the validation in the actual system(s) it is targeted for so it should be fairly apparent how determining the number of devices/units under test (DUT/UUT) can be challenging with the number of printed circuit assembly (PCA) bill-of-material (BOM) combinations that will only grow exponentially with each extra source added to the mix. Some key questions to consider are as follows:

- Has the program manager allocated (and therefore also budgeted) a sufficient number of (prototype) UUTs to accomplish the requisite testing?
- How long will there testing take and at what stage in the development schedule?
- If the schedule is very tight, then is there any contingency planning for when a proto fails highly-accelerated life testing (HALT) or exceeds electromagnetic interference (EMI) class limits?
- Does this align with the power solution release target AND the system release target?

Supply Chain Management personnel are likely to be driven more by opportunities for cost reduction and tend to view multisourcing as a helpful tool for driving AOS. The latter point is debated in the previous white paper and will not be repeated here, but please be sure to investigate component availability and lead times on a line-by-line basis. The determination/qualification of a "critical" component was discussed above, but that is still a different discussion from how a second-source component is determined to be considered "equivalent" to a primary source. Again the quotes are not to be cheeky, but to emphasize the point this can be a very relative term and the semantics of which are inexorably tied to everyone's success. Unfortunately, it is all too common these days for equivalence to be determined by some very fundamental figures of merit (FOM) and cost (typically, with highly inequitable weighting).

While this point is most salient in components that tend to be more sensitive to environmental/application factors (i.e. – semiconductor devices), it can be just as applicable to the simplest of passives (i.e. – resistors). Two different sources for a metal–oxide–semiconductor field-effect transistor (MOSFET) may have the same package/footprint, drain-to-source (a.k.a. – blocking) voltage, and gate voltage, but can still have drastically different gate charge or input/output capacitances. While this may be irrelevant for a small-signal, switching application, it can make all the difference in the world when used in a power FET application. Two different 1k resistors in the same package style and thermal rating may still have slightly different footprints, material composition, or termination styles. The different sources may still likely be characterized as dual sources under the internal part number in the company's approved vendor list (AVL), which means either source is considered qualified to be used interchangeably and leads to major performance risks.

It is natural to want to define rules to help simplify complicated developments and implement processes for what may be perceived as optimizing for time/cost, but multisourcing is one of those particularly touchy areas in which being too generic or restrictive can be highly counterintuitive to meeting ultimate project goals. A simple example of this is that low-volume designs should have a totally different approach than high-volume designs. Low-volume designs tend to be more specialized, can have more aggressive/ruggedized specifications, and be less cost sensitive. High-volume designs tend to have more stringent quality requirements, have increased risk from AOS, and have the overall economic viability be tied to tightly-controlled component, manufacturing, and qualification costs.

A last, key topic in this discussion about how to effectively manage supply chain stakeholders in Commodities Management revolves around business continuity planning (BCP) support [2]. BCP is all about contingency planning against major interruptions, such as is the case for disaster recovery and mitigating enterprise resource planning (ERP, [3]) bottlenecks. While these typically involve tasks for those Commodities Management groups and the resources they associate with, it is always good practice for the power design resource/owner to keep abreast of these processes and the planned actions in the case of a disaster, whether it be from an act of God or a severe supply issue (i.e. – regulatory/embargo/customs). A worst-case scenario can be when an entire factory (or even region) is taken out by a natural disaster and a completely new operation must be transferred and quickly brought back up to equivalent quality output.



This topic may seem a little ancillary to a design engineering stakeholder, but just about every aspect of the design from component selection to assembly instructions to qualification testing is tied to the ability to drive BCP. It can also apply from the highest level (i.e. – system) to the lowest level (i.e. – component) and even get down to the raw materials when one really drills deep. The management aspects between team stakeholders can be bidirectional because a sudden flood or conflict mineral may quickly be the reason you wake up one day and find yourself on the next flight to Thailand that evening to live there for the next 2-3 months, while bringing a new build/ test process online. This is where all the assessment strategy discussed in the previous white paper provides the greatest value when needing to translate into actionable management.

Some key questions to consider are as follows:

- How recently was the target organization's quality management system (QMS) and/or BCP audited?
 How familiar is Design Engineering with a resulting report and driving any corrective action (as appropriate)?
- How quickly can your organization implement a conversion (from partial to full, catastrophic scenarios) from one geographic location to another?
- Do you have specialized (perhaps too specialized of) processes that require a lot of operator training and tightly-controlled actions?
- Does a new region have tariffs or stringent customs staging requirements that will drastically hamper your ability to fully duplicate what was in place before?

ENTERPRISE RESOURCE PLANNING (ERP)

As mentioned before, ERP is important directly to the technical solution at hand as well as supporting the solution both in development and the field (i.e. – sustaining). Component availability can tie directly into design constraints and reduce the accuracy of design calculations for the most critical (and typically most expensive) components, adding severe risk to the design. Excessive lead times, end-of-life (EOL) components, and items with strong dependencies of limited resources (i.e. – rare-earth metals, helium for manufacturing, etc.) can render a desired component unattainable and/or adds considerable risk/cost to final system assembly and deployment. Do you ever specify a 1% tolerance resistor when a 5% is suffice?

It is common to think of ERP mostly in terms of software and other tools used for managing large, complex resources. But in the context of a power solution designer's perspective, these designations and traditional ERP tools may take on a slightly skewed interpretation. Furthermore, traditional ERP involves areas and stakeholders the power designer may typically prefer to stay far away from, like Sales, Corporate Governance, and even Human Resources. Like it or not, it is very self-serving to put some effort into understanding the key objectives/tools/processes driven by stakeholders like these as they inevitably will be critical to your success at one point or another.

To support the aforementioned point, it seems useful to review a handful of these different stakeholder perspectives to enhance understanding of how their bottom line may tie directly to ones in power. Therefore, with a better understanding of the resource and what drives them, comes an enhanced ability to work with these resources, gain more proactive intelligence on mitigating risk, and open direct lines of communication to drive the most efficient management action.

There are more obvious items in the ERP toolbox, like Production Planning and Asset Management, which are fairly intuitive in terms of needing to work with commodities management and manufacturing/test engineers to validate a build plan and mitigate any supply gaps. Less obvious in those areas may be the need to negotiate for and share resources, whether it be a limited number of long-lead-time integrated circuits (IC) used in multiple systems or working with the manufacturing line manager to get your project moved further up the queue when the same line must be reconfigured for multiple products. An organization may have new sustainability targets that put a detailed eye on embodied energy [4] and constraints on carbon/water footprints, which can hamper production.



It is rare to meet a design engineer that professes their love of working with Sales/Marketing partners, but these also tend to be the resources with the most direct access to the voice of the customer and the first ones to take a crack at defining the critical requirements for the functional specification. Buffering design engineers from this direct exposure may be the will of some (on both sides), but ultimately leads to communication gaps and misunderstandings that present themselves at the most inconvenient of times (see "Murphy's Law"). Furthermore, it is common for the stakeholders with the most direct access to the field to also be the least technically detailed and therefore may miss items in translation. Even Accounting requirements and tools must be understood at a basic level since there may be processes (i.e. – paperwork with long approval chains to add a new vendor to the AVL) or terms (i.e. – NET60 payment terms when your vendor will only accept NET45) that are prohibitive to the terms of the resource you are trying to procure.

There are plenty of markets/applications/customers that have very specific constraints to consider and standards to adhere to, which may go far beyond what an organization's designers are traditionally accustomed to. In military/aerospace markets, perhaps only domestic vendors are permitted or the solution requires conductive/passive cooling. In transportation/railway applications, the solutions may be subject to regional standards, be highly robust, and see the extremes of electrical and environmental parameters. In medical devices, there may be incredibly stringent, ultra-low leakage current requirements that must still be met in the midst of extraordinarily long and costly approval processes. Working with customers and direct ERP stakeholders will fast-track these learning curves.



WORKING WITH THE POWER SOLUTION VENDOR

In most cases, the "customer is always right approach" will likely come back to bite you. When dealing with a major, critical, system component such as the power solution, mitigating risk by ensuring an equitable arrangement between all parties is highly desirable. This should become dogma for any design engineering stakeholder working with external solution providers. If a solution is not profitable for a vendor, then why would they want to produce it for you? In very competitive times, will a vendor want to deprioritize your product over a competitor's because of financial viability?

Excessive qualification/testing/QMS requirements may inhibit manufacturing throughput and severely degrade the vendor's profit margin, which will add significant risk to the power solution supply chain. This also typically translates directly to systems manufacturing and line stops that weigh heavy on the financial bottom line.

In practice, we sometimes provide a long list of standards, specifications, and compliance requirements because that is the established



routine and/or because that is the current, corporate process. But not all pegs are square-shaped and not all holes are round. In other words, it can be highly, mutually beneficial to sometimes waive requirements that are not necessarily justified by the complexity of the design or the unit's cost target or volume/quality targets. Aside from the cost (in time and money) savings, this will help everyone involved to spare some cycles and put the resources where they can provide the most value. A vendor will also very much appreciate this kind of action in a tough negotiation and recognize the kind of customer that values their relationship and approaches things with a degree of fairness and pragmatism.

It is far more amenable for ALL parties involved to take a collaborative approach in which everyone's success is tied to the success of the strength of the collaboration. This point is particularly important when the many sticking points and inhibitors identified in this white paper come to fruition (and I promise some will on every development). The difference between a vendor that will tolerate you (perhaps even temporarily bend to your will) and one that will bend over backwards to work with you and get your power solutions shipped is tied very closely to this point as well.

SUMMARY/CONCLUSIONS & FOLLOW-ON INFO

Power designs must be functional and robust across a wide spectrum of operating and environmental factors. This is not achieved purely through excessive calculation, but with real (e.g. – non-ideal and inconsistent) components. Furthermore, if there is no supply, then there is no power, which means there is no system, which means there is no revenue. There are many stakeholders and considerations that engineers focused on delivering power solutions would much rather be isolated from to focus on their "core" competencies, but at the end of the day, experience dictates otherwise.

It takes a lot of engineers some very painful, expensive, and timely, negative experiences before they start to put a sharper focus on the many topics reviewed in this white paper, which may otherwise seem ancillary at first blush. Design equations do not tend to change much, but supply chains are quite dynamic. As one becomes more experienced, they will find themselves committing an increasing amount of their cycles to these supply chain (and related) management needs.

Be sure to request tangibles like the BCP and ERP documents from the appropriate stakeholders to get a first-order experience on what goes into such comprehensive, convoluted planning processes. Surely, there will be plenty of items in there directly tied to your daily activities, or at the very least, will contain some surprises you may be beholden to in the future, and should therefore wrap your head around as early in your career as possible (and continue the professional development in parallel with growth in more engineering/ technical topics).

REFERENCES

- 1. Wikipedia contributors, "Monte Carlo method," Wikipedia, The Free Encyclopedia, https://en.wikipedia.org/w/index.php?title=Monte_Carlo_method&oldid=1098636182 (accessed July 27, 2022).
- 2. Wikipedia contributors, "Business continuity planning," Wikipedia, The Free Encyclopedia, https://en.wikipedia.org/w/index.php?title=Business_continuity_planning&oldid=1103382005 (accessed August 5, 2022).
- Wikipedia contributors, "Enterprise resource planning," Wikipedia, The Free Encyclopedia, https://en.wikipedia.org/w/index.php?title=Enterprise_resource_planning&oldid=1102550774 (accessed August 5, 2022).
- 4. Wikipedia contributors, "Embodied energy," Wikipedia, The Free Encyclopedia, https://en.wikipedia.org/w/index.php?title=Embodied_energy&oldid=1071177420 (accessed August 8, 2022).

Committed to excellence





Find your regional Rutronik contact!



info@rutronik.com | www.rutronik.com